



Features:

- True sine wave output (THD<3%)
- High surge power up to 3000W
- U.P.S. mode and energy saving mode (selectable)
- High efficiency up to 91%
- Power ON-OFF switch
- Standby saving mode can be selectable
- Front panel indicator for operation status
- Thermostatically controlled cooling fan
- Protections: Bat. low alarm / Bat. low shutdown / Over voltage / Over temp. / Output short / Input polarity reverse / Overload / AC circuit breaker
- Application : Home appliance, power tools, office and portable equipment, vehicle and yacht ...etc.
- Built-in solar / AC charger
- Optional monitoring software
- 2 years warranty



SPECIFIC	ATION			,						
MODEL		TN-1500-112	TN-1500-124	TN-1500-148	TN-1500-212	TN-1500-224	TN-1500-248			
	RATED POWER (Typ.)	1500W								
ОИТРИТ	MAXIMUM OUTPUT POWER	1725W for 180 sec. / 2250W for 10 sec. / surge power 3000W for 30 cycles								
	ACVOLTACE	Factory setting set at 110VAC Factory setting set at 230VAC								
	AC VOLTAGE	100 / 110 / 115 / 120\	/AC selectable by set	ting button S.W	200 / 220 / 230 / 240VAC selectable by setting button S.W					
	FREQUENCY	60±0.1Hz 50/60Hz	selectable by setting	button S.W	50±0.1%Hz 50/60Hz selectable by setting button S.W					
	WAVEFORM	True sine wave (THD<3%) at rated input voltage								
	AC REGULATION (Typ.)	±3.0%								
	TRANSFER TIME	t<10ms inverter by pass								
	SAVING MODE (Typ.)	Load ≦5W will be changed to standby mode								
	FRONT PANEL INDICATOR	Battery voltage level, output load level, saving mode, fault and operation status								
	BAT. VOLTAGE	12V	24V	48V	12V	24V	48V			
	VOLTAGE RANGE (Typ.)Note.1		21 ~ 30VDC	42 ~ 60VDC	10.5 ~ 15VDC	21 ~ 30VDC	42 ~ 60VDC			
	DC CURRENT (Typ.) Note.5		75A	37.5A	150A	75A	37.5A			
NPUT	NO LOAD DISSIPATION	≤18W @ standby saving mode								
	OFF MODE CURRENT DRAW	≥ 10W @ standay saving mode ≤1mA								
	EFFICIENCY (Typ.) Note.2	_	89%	90%	88%	90%	91%			
	BATTERY TYPES	Open & sealed Lead		J J J J	00 /0	3070	J 1 /0			
	FUSE	40A*5	30A*3	30A*2	40A*5	30A*3	30A*2			
BATTERY INPUT PROTECTION	BAT. LOW ALARM	11.3±4%	22.5±4%	45±4%	11.3±4%	22.5±4%	45±4%			
	BAT. LOW ALARM	10.5±4%	21±4%	42±4%	10.5±4%	21±4%	45±4% 42±4%			
				42_4 /0	10.3_4 /	2114/0	42 <u>1</u> 4 /0			
	REVERSE POLARITY	By internal fuse oper		0000 1 500	00°0 5 °0	00°G 5 °G	60°0 5 °0			
	OVER TEMPERATURE	82°C±5°C	82°C±5°C	96°C±5°C	68°C±5°C	68°C±5°C	68°C±5°C			
OUTPUT PROTECTION		Protection type: Shut down o/p voltage, re-power on to recover; by internal RTH3 detect on heatsink of power transistor								
	OUTPUT SHORT	Protection type: Shut down o/p voltage, re-power on to recover 105 ~ 115% load for 180 sec., 115% ~ 150% load for 10 sec.								
	OVER LOAD (Typ.)		<u> </u>							
		* .	t down o/p voltage, re	-power on to recover	100					
	CIRCUIT BREAKER	20A			10A					
	GFCI PROCTECTION	Optional (Only type F		1	None					
	WORKING TEMP. Note.3	0 ~ +40°C @ 100% load ; 60°C @ 50% load								
ENVIRONMENT	WORKING HUMIDITY	20% ~ 90% RH non-condensing								
	STORAGE TEMP., HUMIDITY	-30 ~ +70°C / -22 ~ +158°F, 10 ~ 95% RH								
	VIBRATION	10 ~ 500Hz, 3G 10min./1cycle, 60min. each along X, Y, Z axes								
	SAFETY STANDARDS	UL458 (only for "GFCI" receptacles-Type F) EN60950-1								
SAFETY &	WITHSTAND VOLTAGE	Bat I/P - AC I/P:3.0KVAC Bat I/P - AC O/P:3.0KVAC AC O/P - FG:1.5KVAC								
EMC	EMI CONDUCTION&RADIATION	Compliance to FCC	class A		Compliance to EN55022 class B, 72/ 245/ CEE, 95/ 54/ CE, E-					
	EMS IMMUNITY		To 74	1,054	Compliance to EN61000-4-2,3,4,5,6,8,11 ENV50204					
AC	CHARGE CURRENT (Typ.)	5.5A	2.7A	1.35A						
CHARGER	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%			
SOLAR CHARGER	MAX OPEN CIRCUIT VOLTAGE		45V	75V	25V	45V	75V			
	CHARGE CURRENT (max.)	30A								
	CHARGE VOLTAGE	14.3V±4%	28.5V±4%	57V±4%	14.3V±4%	28.5V±4%	57V±4%			
OTHERS	CONTROL WIRING	RJ11 -RS232 (Optio	,							
	DIMENSION	420*220*88mm (L*V	,							
	PACKING	6.85Kg; 2pcs/14.7Kg/1.61CUFT								
NOTE	1.Output derating capacity re 2.Efficiency is tested by 100 3.Output derating capacity re 4.All parameters not specifie 5.DC current is tested by 150	DW, linear load at 13 eferenced by curve 2 d above are measur	8V, 26V, 52V input v 2. red at rated load, 25	°C of ambient temp	erature.					
	·					File Name	:TN-1500-SPEC 2008			



■ Instructions for TN-1500 monitoring software

1. Installation of TN-1500 unit and PC




Figure 1

2. Explanation of Monitoring Manu

2.1 Main Page




Figure 2

- 1. Setting: Adjustment for output voltage, charging related voltage, frequency, and operation mode. Please refer to Figure 3 for details.
- 2. Statistics: Calculate for the percentage of operating period for each operation mode. Please refer to Figure 4 for details.
- 3. R.C. Power off: Power can be turned ON or OFF at the remote location.
- 4. Pause: Stop refreshing the page of monitoring software.
- 5. Status of unit: Indicating current operating status of TN-1500.
- 6. Signals that display current condition of the unit.



2.2 Setting Page




Figure 3

- 1. User can adjust the settings based on the characteristics of batteries been used: Equalization Voltage, Floating Voltage, Alarm Voltage, and Shut-down Voltage. UPS Mode / Energy Saving Mode selection and AC output voltage and frequency can also be set in this page.
- 2. Read: Read current settings of the unit.
- 3. Write: Write the revised setting into the unit.
- 4. Load: Load in factory default settings.

2.3 Statistic Page





Figure 4

- 1. Start Date: Date that installing the monitoring software.
- 2. Reset Date: Date that resetting the statistics. The Start Date will not be influenced by resetting the statistics or turning off the unit.
- 3. Inverter time rate: Operating period of "Inverter Mode" represents how many percent of the whole operating period.
- 4. Bypass time rate: Operating period of "Bypass Mode" (energy provides directly by the utility) represents how many percent of the whole operating period.
- 5. Shut down rate: Percentage of time period that the unit is under the condition of shut down.
 - * Inverter time rate + Bypass time rate + Shut down rate = 100%
- 6. Solar time rate: Percentage of time period that the solar charger is functioning after turning on the TN-1500 unit.
- 7. Loading average: Average loading after turning on the TN-1500 unit.







■ AC Output Receptacles (optional)


	000				
TYPE-A	TYPE-B	TYPE-C	TYPE-D	TYPE-E	TYPE-F
USA	EUROPE	AUSTRALIA	U.K	JAPAN	GFCI

■ Mechanical Specification


Unit:mm







Type-A



Type-B